

# DRIVER SAFETY FEATURE GUIDE




## PARKING SENSORS



SHIFT INTO REVERSE TO ACTIVATE  
THE FRONT AND REAR PARKING SENSORS



LISTEN FOR THE SPEED OF THE WARNING SOUNDS –  
A CONSTANT TONE MEANS YOU ARE CLOSE TO AN OBJECT



VISUALLY CONFIRM YOUR CAR IS CLEAR  
AND PARK