


DRIVER SAFETY FEATURE GUIDE



BACK-UP CAMERA



LOOK LEFT & RIGHT OVER BOTH SHOULDERS.
CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE THE SYSTEM




AS YOU BACK UP CHECK THE VIDEO MONITOR
AS WELL AS YOUR MIRRORS AND SURROUNDINGS

DRIVER SAFETY FEATURE GUIDE




BACK-UP WARNING SYSTEM



BEFORE BACKING LOOK OVER BOTH SHOULDERS.
CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE.
SYSTEM WARNS YOU IF AN OBJECT IS IN THE WAY.




TURN AND CHECK TO BE SURE
IT IS SAFE BEFORE BACKING.


DRIVER SAFETY FEATURE GUIDE




CROSS TRAFFIC ALERT



BEFORE BACKING LOOK OVER BOTH SHOULDERS.
CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE.




IF A VEHICLE APPROACHES, A TONE AND
FLASHING LIGHT ON MIRROR OR DASHBOARD
WILL ALERT YOU TO STOP. APPLY BRAKE.


DRIVER SAFETY FEATURE GUIDE



ANTI-LOCK BRAKING SYSTEM



APPLY PRESSURE



HOLD PRESSURE



STEER TO SAFETY


DRIVER SAFETY FEATURE GUIDE




FORWARD COLLISION WARNING



FEATURE MONITORS THE TRAFFIC AHEAD



WARNS YOU TO BRAKE IF A HAZARD IS IN YOUR PATH




BRAKE OR STEER TO HELP AVOID OR MINIMIZE A CRASH


DRIVER SAFETY FEATURE GUIDE



AUTOMATED BRAKING



FEATURE DETECTS IF A HAZARD IS IN YOUR PATH



ALERTS YOU WITH SOUND OR DASH LIGHT




IF YOU DON'T RESPOND IN TIME TO THE
WARNING, THE CAR MAY SLOW DOWN OR STOP
TO HELP AVOID A CRASH


DRIVER SAFETY FEATURE GUIDE




BLIND SPOT MONITORING



ALERTS YOU WHEN A VEHICLE ENTERS YOUR BLIND SPOT



WARNING ICON LIGHTS UP. IF YOU ENGAGE TURN SIGNAL, WARNING ICON WILL BLINK AND YOU MAY HEAR AN ALERT.




REMEMBER TO LOOK OVER YOUR SHOULDER AND USE TURN SIGNALS BEFORE CHANGING LANES


DRIVER SAFETY FEATURE GUIDE




SIDVIEW CAMERA



TO ACTIVATE, USE THE TURN SIGNAL OR PRESS
A BUTTON ON THE TURN SIGNAL LEVER



LOOK AT THE VIDEO DISPLAY TO SEE A VIEW
OF THE ROAD ON EITHER SIDE OF YOUR CAR



ALWAYS LOOK OVER YOUR SHOULDERS AND
USE SIDE MIRRORS TOO

DRIVER SAFETY FEATURE GUIDE



LANE DEPARTURE WARNING



ALERTS YOU WHEN DRIFTING OUT OF YOUR LANE



ALERTS YOU WITH SOUND, ICON OR VIBRATION



FEATURE DOES NOT ALERT DRIVER WHEN THE TURN SIGNAL IS ACTIVATED

DRIVER SAFETY FEATURE GUIDE



LANE KEEPING ASSIST



WILL ALERT YOU WITH A SOUND, FLASHING LIGHT OR VIBRATION IF YOU DRIFT OUT OF YOUR LANE



IF YOU DO NOT RESPOND TO THE WARNING, THE FEATURE WILL GENTLY STEER THE CAR BACK TOWARD THE CENTER OF THE LANE



A SLIGHT PULL OF THE WHEEL BY THE DRIVER WILL DISABLE THE FEATURE


DRIVER SAFETY FEATURE GUIDE



TIRE PRESSURE MONITORING SYSTEM



IF THIS SYMBOL APPEARS – TIRES ARE DANGEROUSLY UNDER- OR OVER-INFLATED



IF DRIVING, SAFELY PULL OVER TO CHECK EACH TIRE'S PRESSURE FOR UNDER- OR OVER-INFLATION

TIRE AND LOADING INFORMATION			
SEATING CAPACITY		TOTAL X	FRONT X, REAR X
combined weight of occupants and cargo should never exceed XXX kg or XXX lbs. See owner's manual for proper distribution. Always use proper tie-down technique. Always use proper tie-down technique.			
WHEEL	SIZE	COLD TIRE PRESSURE	SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
FRONT	PXXX/XXRXX	XXXKPA, XXPSI	
REAR	PXXX/XXRXX	XXXKPA, XXPSI	
SPARE	PXXX/XXRXX	XXXKPA, XXPSI	


↑
Proper inflation

PROPERLY INFLATE TIRES TO RECOMMENDED PRESSURE


DRIVER SAFETY FEATURE GUIDE



ADAPTIVE CRUISE CONTROL



SET DESIRED SPEED



SET DESIRED FOLLOWING DISTANCE



STAY FOCUSED.
INCREASE FOLLOWING DISTANCE IN
POOR CONDITIONS.


DRIVER SAFETY FEATURE GUIDE



ELECTRONIC STABILITY CONTROL



ELECTRONIC STABILITY CONTROL IS AUTOMATICALLY ON WHEN YOU START YOUR CAR.



ESC ENGAGES AUTOMATICALLY TO PREVENT OVERSTEERING AND UNDERSTEERING.




ESC WORKS BY BRAKING INDIVIDUAL WHEELS AND REDUCING ENGINE SPEED – HELPING YOU MAINTAIN CONTROL.

DRIVER SAFETY FEATURE GUIDE



DROWSINESS ALERT



IF DRIVING IN AND OUT OF YOUR LANE, THE FEATURE WILL ALERT YOU WITH SOUND, VISUAL WARNING OR VIBRATION



ALWAYS DRIVE ALERT AND GET PLENTY OF REST



REMEMBER DON'T DRIVE DISTRACTED

DRIVER SAFETY FEATURE GUIDE



ADAPTIVE HEADLIGHTS



ADAPTIVE HEADLIGHTS ADJUST TO HELP YOU SEE
ON DARK CURVED ROADS AND OVER HILLS



THEY MOVE WHEN YOU STEER




REMEMBER TO ALWAYS SCAN THE ROAD AHEAD


DRIVER SAFETY FEATURE GUIDE




AUTOMATIC PARALLEL PARKING



PRESS THE PARK BUTTON, FIND A PARKING SPACE
AND PULL FORWARD



SHIFT INTO REVERSE, RELEASE THE BRAKE SLIGHTLY,
AND RELEASE THE STEERING WHEEL




AUTOMATIC PARKING TAKES OVER AND DIRECTS
YOU WHEN TO SHIFT INTO DRIVE

DRIVER SAFETY FEATURE GUIDE




PARKING SENSORS



SHIFT INTO REVERSE TO ACTIVATE THE FRONT AND REAR PARKING SENSORS



LISTEN FOR THE SPEED OF THE WARNING SOUNDS – A CONSTANT TONE MEANS YOU ARE CLOSE TO AN OBJECT



VISUALLY CONFIRM YOUR CAR IS CLEAR AND PARK

DRIVER SAFETY FEATURE GUIDE




PUSH BUTTON START



MAKE SURE THE KEY FOB IS INSIDE THE VEHICLE



STEP ON AND HOLD BRAKE, PUT GEAR SHIFT IN PARK



PUSH AND HOLD BUTTON UNTIL ENGINE STARTS
OR SHUTS OFF