


BLIND SPOT MONITOR



ALERTS YOU WHEN A VEHICLE ENTERS YOUR BLIND SPOT



WARNING ICON LIGHTS UP. IF YOU ENGAGE TURN SIGNAL, WARNING ICON WILL BLINK AND YOU MAY HEAR AN ALERT.




REMEMBER TO LOOK OVER YOUR SHOULDER AND USE TURN SIGNALS BEFORE CHANGING LANES









LANE DEPARTURE WARNING



ALERTS YOU WHEN DRIFTING OUT OF YOUR LANE



ALERTS YOU WITH SOUND, ICON OR VIBRATION



FEATURE DOES NOT ALERT DRIVER WHEN THE TURN SIGNAL IS ACTIVATED










BLIND SPOT MONITORING



ALERTS YOU WHEN A VEHICLE ENTERS YOUR BLIND SPOT



WARNING ICON LIGHTS UP. IF YOU ENGAGE TURN SIGNAL, WARNING ICON WILL BLINK AND YOU MAY HEAR AN ALERT.



REMEMBER TO LOOK OVER YOUR SHOULDER AND USE TURN SIGNALS BEFORE CHANGING LANES









LANE KEEPING ASSIST



WILL ALERT YOU WITH A SOUND, FLASHING LIGHT OR VIBRATION IF YOU DRIFT OUT OF YOUR LANE



IF YOU DO NOT RESPOND TO THE WARNING, THE FEATURE WILL GENTLY STEER THE CAR BACK TOWARD THE CENTER OF THE LANE



A SLIGHT PULL OF THE WHEEL BY THE DRIVER WILL DISABLE THE FEATURE












SIDEVIEW CAMERA



TO ACTIVATE, USE THE TURN SIGNAL OR PRESS A BUTTON ON THE TURN SIGNAL LEVER



LOOK AT THE VIDEO DISPLAY TO SEE A VIEW OF THE ROAD ON EITHER SIDE OF YOUR CAR



ALWAYS LOOK OVER YOUR SHOULDERS AND USE SIDE MIRRORS TOO









ADAPTIVE CRUISE CONTROL



SET DESIRED SPEED



SET DESIRED FOLLOWING DISTANCE



STAY FOCUSED.
INCREASE FOLLOWING DISTANCE IN POOR CONDITIONS.









FORWARD COLLISION WARNING



FEATURE MONITORS THE TRAFFIC AHEAD



WARNS YOU TO BRAKE IF A HAZARD IS IN YOUR PATH




BRAKE OR STEER TO HELP AVOID OR MINIMIZE A CRASH










AUTOMATED BRAKING



FEATURE DETECTS IF A HAZARD IS IN YOUR PATH



ALERTS YOU WITH SOUND OR DASH LIGHT



IF YOU DON'T RESPOND IN TIME TO THE WARNING, THE CAR MAY SLOW DOWN OR STOP TO HELP AVOID A CRASH









ADAPTIVE HEADLIGHTS



ADAPTIVE HEADLIGHTS ADJUST TO HELP YOU SEE ON DARK CURVED ROADS AND OVER HILLS



THEY MOVE WHEN YOU STEER



REMEMBER TO ALWAYS SCAN THE ROAD AHEAD










AUTOMATIC EMERGENCY BRAKING



FEATURE DETECTS IF A HAZARD IS IN YOUR PATH



ALERTS YOU WITH SOUND OR DASH LIGHT



IF YOU DON'T RESPOND IN TIME TO THE WARNING, THE CAR MAY SLOW DOWN OR STOP TO HELP AVOID A CRASH










ANTI-LOCK BRAKING SYSTEM



APPLY PRESSURE



HOLD PRESSURE



STEER TO SAFETY










TRACTION CONTROL




HELPS PREVENT WHEELS FROM SPINNING
ON SLIPPERY SURFACES AND INCREASES TRACTION
WHEN ACCELERATING



TURN OFF TRACTION CONTROL

IF STUCK IN MUD OR SNOW AND NEED TO ROCK
THE CAR OR WHEN USING TIRE CHAINS



TRACTION CONTROL WILL ONLY ENGAGE WHEN YOUR WHEELS START TO SLIP










ELECTRONIC STABILITY CONTROL



ELECTRONIC STABILITY CONTROL IS AUTOMATICALLY ON WHEN YOU START YOUR CAR.



ESC ENGAGES AUTOMATICALLY TO PREVENT OVERSTEERING AND UNDERSTEERING.



ESC WORKS BY BRAKING INDIVIDUAL WHEELS AND REDUCING ENGINE SPEED – HELPING YOU MAINTAIN CONTROL.











TIRE PRESSURE MONITORING SYSTEM



IF THIS SYMBOL APPEARS – TIRES ARE DANGEROUSLY UNDER- OR OVER-INFLATED



IF DRIVING, SAFELY PULL OVER TO CHECK EACH TIRE'S PRESSURE FOR UNDER- OR OVER-INFLATION



PROPERLY INFLATE TIRES TO RECOMMENDED PRESSURE









ENGINE START STOP

PUSH BUTTON START



MAKE SURE THE KEY FOB IS INSIDE THE VEHICLE



STEP ON AND HOLD BRAKE, PUT GEAR SHIFT IN PARK



PUSH AND HOLD BUTTON UNTIL ENGINE STARTS OR SHUTS OFF









DROWSINESS ALERT



IF DRIVING IN AND OUT OF YOUR LANE, THE FEATURE WILL ALERT YOU WITH SOUND, VISUAL WARNING OR VIBRATION



ALWAYS DRIVE ALERT AND GET PLENTY OF REST



REMEMBER DON'T DRIVE DISTRACTED









BACK-UP WARNING



BEFORE BACKING LOOK OVER BOTH SHOULDERS. CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE.
SYSTEM WARNS YOU IF AN OBJECT IS IN THE WAY.




TURN AND CHECK TO BE SURE IT IS SAFE BEFORE BACKING.









BACK-UP CAMERA



LOOK LEFT & RIGHT OVER BOTH SHOULDERS. CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE THE SYSTEM



AS YOU BACK UP CHECK THE VIDEO MONITOR AS WELL AS YOUR MIRRORS AND SURROUNDINGS











CROSS TRAFFIC ALERT



BEFORE BACKING LOOK OVER BOTH SHOULDERS. CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE.






IF A VEHICLE APPROACHES, A TONE AND FLASHING LIGHT ON MIRROR OR DASHBOARD WILL ALERT YOU TO STOP. APPLY BRAKE.









AUTOMATIC PARALLEL PARKING



PRESS THE PARK BUTTON, FIND A PARKING SPACE AND PULL FORWARD



SHIFT INTO REVERSE, RELEASE THE BRAKE SLIGHTLY, AND RELEASE THE STEERING WHEEL



AUTOMATIC PARKING TAKES OVER AND DIRECTS YOU WHEN TO SHIFT INTO DRIVE










PARKING SENSORS



SHIFT INTO REVERSE TO ACTIVATE THE FRONT AND REAR PARKING SENSORS



LISTEN FOR THE SPEED OF THE WARNING SOUNDS – A CONSTANT TONE MEANS YOU ARE CLOSE TO AN OBJECT



VISUALLY CONFIRM YOUR CAR IS CLEAR AND PARK









BACK-UP WARNING SYSTEM




BEFORE BACKING LOOK OVER BOTH SHOULDERS. CHECK MIRRORS.



SHIFT INTO REVERSE TO ACTIVATE.

SYSTEM WARNS YOU IF AN OBJECT IS IN THE WAY.



TURN AND CHECK TO BE SURE IT IS SAFE BEFORE BACKING.





